

Operating and Assembly Instructions

Incremental Hollow-Shaft Encoder FG40

**Read the Operating and Assembly Instructions prior to assembly, starting installation and handling!
Keep for future reference!**

Trademark

Brand names and product names are trademarks or registered trademarks of their respective owner. Protected trademarks bearing a TM or ® symbol are not always depicted as such in the manual. However, the statutory rights of the respective owners remain unaffected.

Manufacturer / publisher

Johannes Hübner
Fabrik elektrischer Maschinen GmbH
Siemensstr. 7
35394 Giessen
Germany
Phone: +49 641 7969 0
Fax: +49 641 73645
Internet: www.huebner-giessen.com
E-Mail: info@huebner-giessen.com

This manual has been drawn up with the utmost care and attention. Nevertheless, we cannot exclude the possibility of errors in form and content. It is strictly forbidden to reproduce this publication or parts of this publication in any form or by any means without the prior written permission of Johannes Hübner Fabrik elektrischer Maschinen GmbH.

Johannes Hübner Fabrik elektrischer Maschinen GmbH is listed by Underwriters Laboratories.

UL certificates can be requested from us.

An overview of our UL devices can be found at the following link:

<https://iq.ulprospector.com/info>

UL File Number: E351535

Type	UL model No.
FGH 40 K	FGH 40 K-XXXX
	FGHJ 40 K-XXXX
	FGH 40 K-XXXX-S
	FGH 40 KK-XXXX
	FGHJ 40 KK-XXXX
FGH 40 L	FGH 40 L-XXXX
	FGHJ 40 L-XXXX
	FGH 40 LL-XXXX
	FGHJ 40 LL-XXXX

Subject to errors and changes due to technical improvements.

Copyright © Johannes Hübner Fabrik elektrischer Maschinen GmbH

All rights reserved.

Directory

1 General	5
1.1 Information about the Operating and Assembly Instructions.....	5
1.2 Scope of delivery	5
1.3 Explanation of symbols	5
1.4 Disclaimer	6
1.5 Copyright	6
1.6 Guarantee terms	6
1.7 Customer service	6
2 Safety.....	6
2.1 Responsibility of the owner	6
2.2 Intended use	6
2.3 Non- intended use.....	7
2.4 Personnel.....	7
2.5 Personal protective equipment.....	7
2.6 Special dangers	8
2.6.1 Electrical current.....	8
2.6.2 Rotating shaft / Hot surfaces	8
2.6.3 Safeguarding against restart.....	8
3 Technical Data	9
3.1 Type plates	9
3.2 Electrical and mechanical data.....	10
3.2.1 For pulse rates (square wave pulses).....	10
3.2.2 Output signals Sine / Cosine	11
3.3 Type code	15
3.3.1 For pulse rates (square wave pulses).....	15
3.3.2 For output signals Sine / Cosine	16
4 Transport, packaging and storage	17
4.1 Safety instructions for transport.....	17
4.2 Incoming goods inspection.....	17
4.3 Packaging / disposal	17
4.4 Storage of packages (devices).....	17
5 Installation and commissioning.....	18
5.1 Safety instructions.....	18
5.2 Technical information	18
5.3 Required tools.....	18
5.4 Mounting preparations	19
5.5 Mounting hollow-shaft type FGH 40	19
5.5.1 Standard (type P with feather key, type K with clamping without feather key).....	19
5.5.2 Hollow shaft with clamping ring and blind hole (type R with inch dimensions).....	21
5.6 Installation.....	22

5.6.1 General rules.....	22
5.6.2 Connecting	23
5.6.3 Shield contacting for EMC cable gland with cone	24
5.6.4 Connecting the fiber optic cable.....	24
5.7 Dismantling	25
5.7.1 Safety instruction.....	25
5.7.2 Dismantling hollow- shaft type FGH 40.....	25
5.8 Electrical connection and start up.....	26
5.8.1 Preparing cables	26
5.8.2 Electrical connection.....	26
6 Faults.....	28
6.1 Faults table	28
7 Inspections.....	29
7.1 Safety instructions.....	29
7.2 Maintenance information	29
7.3 Inspection schedule	29
8 Disposal.....	29
8.1 Disposal procedure	29
9 Spare Parts.....	29
10 Dimension drawings.....	30
10.1 Construction type hollow- shaft	30
11 Connection diagrams	40

1 General

1.1 Information about the Operating and Assembly Instructions

These Operating and Assembly Instructions provide important instructions for working with the device. They must be carefully read prior to starting all tasks, and the instructions contained herein must be followed.

In addition, applicable local regulations for the prevention of industrial accidents and general safety regulations must be complied with.

1.2 Scope of delivery

Incremental Hollow-Shaft Encoder FGH 40, Operating and Assembly Instructions.

1.3 Explanation of symbols

Warnings are indicated by symbols in these Operating and Assembly Instructions. The warnings are introduced by signal words that express the scope of the hazard.

The warnings must be strictly heeded; you must act prudently to prevent accidents, personal injury, and property damage.



WARNING!

Indicates a possibly dangerous situation that can result in death or serious injury if it is not avoided.



CAUTION!

Indicates a possibly dangerous situation that can result in minor injury if it is not avoided.



CAUTION!

Indicates a possibly dangerous situation that can result in material damage if it is not avoided.



NOTES!

Indicates useful tips and recommendations as well as information for efficient and trouble-free operation.



NOTES!

Do not use a hammer or similar tool when installing the device due to the risk of damage occurring to the bearings or coupling!



DANGER!

Life-threatening danger due to electric shock!

Indicates a life-threatening situation due to electric shock. If the safety instructions are not complied with there is danger of serious injury or death. The work that must be executed should only be performed by a qualified electrician.

1.4 Disclaimer

All information and instructions in these Operating and Assembly Instructions have been provided under due consideration of applicable guidelines, as well as our many years of experience.

The manufacturer assumes no liability for damages due to:

- Failure to follow the instructions in the Operating and Assembly Instructions
- Non-intended use
- Deployment of untrained personnel
- Opening of the device or conversions of the device

In all other aspects the obligations agreed in the delivery contract as well as the delivery conditions of the manufacturer apply.

1.5 Copyright



NOTES!

Content information, text, drawings, graphics, and other representations are protected by copyright and are subject to commercial property rights.

It is strictly forbidden to make copies of any kind or by any means for any purpose other than in conjunction with using the device without the prior written agreement of the manufacturer. Any copyright infringements will be prosecuted.

1.6 Guarantee terms

The guarantee terms are provided in the manufacturer's terms and conditions.

1.7 Customer service

For technical information personnel is available that can be contacted by telephone, fax or email. See manufacturer's address on page 2.

2 Safety



DANGER!

This section provides an overview of all the important safety aspects that ensure protection of personnel, as well as safe and trouble-free device operation.

If these safety instructions are not complied with significant hazard can occur.

2.1 Responsibility of the owner

The device is used in commercial applications. Consequently the owner of the device is subject to the legal occupational safety obligations and subject to the safety, accident prevention and environmental protection regulations that are applicable for the device's area of implementation.

2.2 Intended use

The device has been designed and constructed exclusively for the intended use described here.


Series FGH 40 Incremental Hollow- Shaft Encoders are used for measurement of rotations, for instance of electrical and mechanical drives and shafts.

Claims of any type due to damage arising from non-intended use are excluded; the owner bears sole responsibility for non-intended use.

For UL and CSA:

For the use in NFPA 79 applications only.

2.3 Non- intended use

	Warning: This device is not intended for use in residential areas and cannot ensure adequate protection of radio reception in such environments.
---	--

Do not use the device in potentially explosive areas.

The device must not be subjected to mechanical loads in addition to its own weight and unavoidable vibration and shock loads that arise during normal operations.

Examples for non-permitted mechanical loads (incomplete list):

- Fastening transport or lifting tackle to the device, for example a crane hook to lift a motor.
- Fastening packaging components to the device, for example ratchet straps, tarpaulins etc.
- Using the device as a step, for example by people to climb onto a motor.

2.4 Personnel

Installation and commissioning as well as disassembly routines must be carried out by skilled technical staff only.

2.5 Personal protective equipment

Wear personal protective equipment such as safety shoes and safety clothing to minimise risks to health and safety when carrying out work such as installation, disassembly or commissioning. Adhere to all applicable statutory regulations as well as the rules and standards determined by the owner.

2.6 Special dangers

Residual risks that have been determined based on a risk assessment are cited below.

2.6.1 Electrical current



DANGER!

Life-threatening danger due to electrical shock!

There is an imminent life-threatening hazard if live parts are touched. Damage to insulation or to specific components can pose a life-threatening hazard.

Therefore:

Immediately switch off the device and have it repaired if there is damage to the insulation of the power supply.

De-energize the electrical equipment and ensure that all components are connected for all tasks on the electrical equipment.

Keep moisture away from live parts. Moisture can cause short circuits.

2.6.2 Rotating shaft / Hot surfaces



WARNING!

Danger of injury due to rotating shafts and hot surfaces!

Touching rotating shafts can cause serious injuries.

Therefore:

Do not reach into moving parts/shafts or handle moving parts/shafts during operation. Close to protect from injury all access openings in flanges with the corresponding plug screw, and provided you exposed rotating components with protective covers.

Do not open covers during operation. Prior to opening the covers ensure that all parts have come to a standstill.

The encoder can become hot during prolonged use.

In case of contact risk of burns is existing.

2.6.3 Safeguarding against restart



DANGER!

Life-threatening danger if restarted without authorization!

When correcting faults there is danger of the power supply being switched on without authorization.

This poses a life-threatening hazard for persons in the danger zone.


Therefore:

Prior to starting work, switch off the system and safeguard it from being switched on again.

3 Technical Data

3.1 Type plates

Below are some Example nameplates for different device models shown.




Device with one terminal box



Device with two terminal boxes (redundant version)



Device with integrated option S



Device with 2 sinusoidal signals



Without UL-Certification

Without UL-Certification

The nameplate and UKCA label are located on the side of the housing.

Nameplate information:

- Manufacturer, Address
- Type
- CE marking
- Serial number (S/N)
- Commission number (C/N)
- Year of construction
- Pulse rate
- Protection class
- Power supply
- No-load current
- Outputs
- Certification references
- QR-Code

3.2 Electrical and mechanical data

3.2.1 For pulse rates (square wave pulses)

Pulse rates	Value
Standard pulse rates	500, 600, 1000, 1024, 1200, 2000, 2048, 2400, 2500
Special pulse rates	4000, 4096, 4800, 5000, 8192, 10000, 12000, 16000, 16384, 20000, 25000, 40000, 50000 (further pulse rates according to customers specification)

Connection data

Supply voltage	12 V ... 30 V DC For UL and CSA Class 2 supplied
No load-current	approx. 50 mA at 24 V
Outputs	Current limited, short-circuit proof push-pull line driver with integrated impedance adaptation for 30 to 140 Ω lines.
Pulse height (HTL)	approx. as supply voltage, output saturation voltage < 0.4 V at I_L 30 mA
Output current	max. 150 mA at 24 V (observe derating)
Internal resistance	75 Ω bei 24 V
Slew rate	200 V / μ s with C_L 100 pF

Duty cycle	1 : 1 \pm 3 % for standard pulse rates 1 : 1 \pm 5 % for special pulse rates up to 25000 pulses
Square wave displacement 0°, 90°	90° \pm 3 % for standard pulse rates 90° \pm 5 % or special pulse rates up to 25000 pulses
Max. frequency	200 kHz, Higher max. frequency on request

Special output voltage 5V (TTL)

Pulse height	5V, RS422-compatible (TIA/EIA-Standard)
Supply voltage	12 ... 30 V DC (optional: 5 V DC) For UL and CSA Class 2 supplied

3.2.2 Output signals Sine / Cosine

Pulse rates	Value
Standard pulse rates	500, 600, 1000, 1024, 1200, 2000, 2048, 2400, 2500
Connection data	
Supply voltage	5 V ... 30 V DC For UL and CSA Class 2 supplied
No load-current	Approx. 120 mA at 5 V, approx. 50 mA at 24 V
Max. frequency	200 kHz, higher max. frequency on request
Output signals	2 sinusoidal signals A and B each with inverted signals Reference pulse with inverted signal Signal amplitude 1 V pp / $R_L = 120 \Omega$ Error signal and inverted signal Signal amplitude 5V
Resolution	1024 signal perodes
Duty cycle	$1 \pm 0,1$
Phase shift A, B	$90^\circ \pm 1^\circ$

Protection class acc. to DIN EN 60529	Sealing	Permissible speed	Rotor moment of inertia	Breakaway torque
IP 65	Standard	$\leq 4000 \text{ rpm}$ (*) $\leq 3000 \text{ rpm}$	approx. 1175 gcm ²	approx. 10 Ncm
IP 66	with labyrinth seal	$\leq 4000 \text{ rpm}$ (*) $\leq 3000 \text{ rpm}$	approx. 1325 gcm ²	approx. 10 Ncm
IP 66	with axial shaft seal	$\leq 2000 \text{ rpm}$ (*) $\leq 2000 \text{ rpm}$	approx. 1175 gcm ²	approx. 25 Ncm
IP 66	with radial shaft seal (for special applications, e.g. wet areas in rolling mills)	$\leq 2000 \text{ rpm}$ (*) $\leq 2000 \text{ rpm}$	approx. 1175 gcm ²	approx. 30 Ncm
(UL/CSA Type 1)				

(*) type FGHJ 40 (isolated bearings)

Vibration resistance	DIN EN 60068-2-6 / IEC 68-2-6 (10 ... 2000 Hz)	20 g (=200 m/s ²)
Shock resistance	DIN EN 60068-2-27 / IEC 68-2-27 (6 ms)	150 g (=1500 m/s ²)
Weight	Type FGH 40 K Type FGH 40 KK	approx. 4,2 kg approx. 4,5 kg

Encoder temperature range

Standard	0°C... + 70°C
Special temperature	-25°C... + 85°C -40°C... + 85°C -5°C... + 100°C (UL/CSA: max. + 70°C)

The FG 40 is categorised in Group 1 and Class A in accordance with EN 55011 and is only intended for use in an industrial environment.









WARNING!

For hollow shafts with an inner diameter smaller than Ø 15 mm / Ø 0.59 inch, make sure that the vibration load is adapted.



NOTES!

The hollow shaft device FGH 40 reduces the degree of protection to IP 65, if the cover plate is not mounted. At maximum speed the permissible ambient temperature will be reduced to 60°C.

Signal outputs for pulse rates (square wave pulses)	
Basic version Basic channel 0° (A) and pulse channel 90° (B) Internal system diagnostics with error output (ERROR) Each with inverted signals	$\begin{matrix} 0^\circ \\ \overline{0^\circ} \end{matrix}$  $\begin{matrix} 90^\circ \\ \overline{90^\circ} \end{matrix}$ 
Option N Reference pulse (N) mechanically defined; one square-wave pulse per revolution; with inverted signal	$\begin{matrix} N \\ \overline{N} \end{matrix}$ 
Option 2F Twice as many pulses as basic channel by combining the 0° and 90° channels	$\begin{matrix} 2F \\ \overline{2F} \end{matrix}$ 
Option B Rapid direction of rotation detection at each edge of the 0° and 90° channels Can be combined with Option F	$\begin{matrix} B \\ \overline{B} \end{matrix}$ $\begin{matrix} \text{CW} \curvearrowright \\ \text{CW} \curvearrowleft \end{matrix}$ $\begin{matrix} \text{CCW} \curvearrowleft \\ \text{CCW} \curvearrowright \end{matrix}$
Option B2 Rapid direction of rotation detection at each edge of the 0° and 90° channels; additional standstill recognition	$\begin{matrix} B2 \\ \overline{B2} \end{matrix}$ $\begin{matrix} \text{CW} \curvearrowright \\ \text{CW} \curvearrowleft \end{matrix}$ $\begin{matrix} \text{CCW} \curvearrowleft \\ \text{CCW} \curvearrowright \end{matrix}$...  STOP
Option B3 Rotation-dependent output signals. This option supports counter cards with separate UP/DOWN pulse inputs. Basic channel signals are issued at option output 1 when rotation is clockwise and at option output 2 when rotation is counterclockwise.	$\begin{matrix} O1 \\ O2 \end{matrix}$ $\begin{matrix} \text{CW} \\ \text{CW} \end{matrix}$  $\begin{matrix} \text{CCW} \\ \text{CCW} \end{matrix}$
Option S Electronic overspeed switch with two independently programmable switching points	See separate Operating and Assembly Instructions EGS® 40
Fiber optic option As an alternative to conventional signal transmissions via copper cables encoder signals can also be transmitted via fiber optic cables.	Max. frequency 100 kHz

The signal sequence 0°, 90° applies for clockwise rotation seen from the drive shaft direction. To obtain the same signal sequence for counter clockwise rotation the clamp 0°, 90° has to be connected see connection diagram.









Signal outputs for output signals sine / cosine

Basic channel 0° (A) and pulse channel 90° (B).

Reference pulse (N) mechanically defined; one square-wave pulse per revolution; with inverted signal

Each with inverted signal.

Internal system diagnostics with error output (ERROR).

A+		Ausgang A+	Output A+
A-		Ausgang A-Invers	Output A-Inverse
B+		Ausgang B+	Output B+
B-		Ausgang B-Invers	Output B-Inverse
N+		Ausgang Nullimpuls	Output Reference
N-		Ausgang Nullimpuls Invers	Output Reference Inverse
ERR		Fehlerausgang (Low aktiv)	Error Output (Low aktiv)
$\overline{\text{ERR}}$		Fehlerausgang (High aktiv)	Error Output (High aktiv)

3.3 Type code

3.3.1 For pulse rates (square wave pulses)

	FGH	J	40	K	1024	G	90G	NG	2F	S	/20P
Incremental hollow-shaft encoder											
Isolated bearings											
Series											
connections, radial design											
K: Terminal box											
R: Burndy®-plug											
C: Connection cable											
L: Fiber optic connection											
S: 15-pole EMC industrial plug											
KK: 2 terminal boxes, i.e. redundant version or with option S											
further combined connections available											
Pulses per revolution											
Basic signal output											
Basic channel 0° (A)											
Pulse channel 90° (B)											
Each with inverted signals											
NG: Option reference pulse with inverted signal											
N2: Reference pulse, mechanically fixed with LED check (red) for display of reference pulse											
2F: Option 2F											
B: Option B											
B2: Option B2											
B3: Option B3											
S: Option S											
Inner diameter (by hollow shaft design)											
20 P (standard) P: feather key											
16 P, 19P, (optional)											
16 K, 25 K (optional) K: clamping											
Blind hollow shafts with inch dimensions (Anglo-American dimensional system)											
0.375R R: clamping with clamping ring without feather key											
0.500R											
0.625R											
0.750R											
0.875R											
1.000R											

3.3.2 For output signals Sine / Cosine

	FGH	J	40	K	1024	S	N	/20P
Incremental hollow-shaft encoder								
Isolated bearings								
Series								
connections, radial design								
K: Terminal box								
R: Burndy®-plug								
C: Connection cable								
S: 15-pole EMC industrial plug								
KK: 2 terminal boxes, i.e. redundant version								
Resolution								
1024 signal periods per revolution								
Output signals								
2 sinusoidal signals A and B each with inverted signals								
NG: Option reference pulse with inverted signal								
Inner diameter (by hollow shaft design)								
20 P (standard) P: feather key								
16 P, 19P, (optional)								
16 K, 25 K (optional) K: clamping								
Blind hollow shafts with inch dimensions (Anglo-American dimensional system)								
0.375R R: clamping with clamping ring without feather key								
0.500R								
0.625R								
0.750R								
0.875R								
1.000R								

4 Transport, packaging and storage

4.1 Safety instructions for transport

**CAUTION!****Material damage caused by improper transport!**

Observe the symbols and information on the packaging:

- Do not throw - risk of breakage
- Keep dry
- Do not expose to heat above 40 °C or direct sunlight.

4.2 Incoming goods inspection

Check delivery immediately upon receipt for completeness and possible transport damage.

Inform the forwarder directly on receipt of the goods about existing transport damages (prepare pictures for evidence).


4.3 Packaging / disposal

The packaging is not taken back and must be disposed of in accordance with the respective statutory regulations and local guidelines.

4.4 Storage of packages (devices)

**Keep dry**

Keep packages dry and free from dust; protect from moisture.

**Protect against heat**

Protect packages from heat above 40 °C and direct sunlight.

If you intend to store the device for a longer period of time (> 6 months) we recommend you use protective packaging (with desiccant).

**NOTES!**

Turn the shaft of the device every 6 month to prevent the bearing grease solidifying!

5 Installation and commissioning

5.1 Safety instructions

**NOTES!**

Observe the safety instructions contained in **Chapter 2** when installing or working on the device!

Personnel

Installation and commissioning must be carried out by skilled technical staff only.

5.2 Technical information

**NOTES!**

Do not use a hammer or similar tool when installing the device due to the risk of damage occurring to the bearings or coupling!

Ambient temperature

The max. permissible ambient temperature depends on the speed and degree of protection of the device, the signal frequency, the length of the signal cable and the place of installation (please refer to Chapter 3.2).

Degree of protection

To fulfil degree of protection requirements the diameter of the connection cable must correspond to that of the cable gland (please refer to Chapter 10 Dimension drawings)!

Deep groove ball bearings

FGH 40 incremental hollow- shaft encoders are fitted with maintenance-free, greased "for-life" deep groove bearings. Bearings must be changed by the manufacturer only. Opening the encoder renders the guarantee null and void.

Screw retention

We recommend using Loctite® 243 thread locker (medium strength) on all fastening screws to prevent loosening.

5.3 Required tools

- Spanners: 10 mm, 14 mm, 22 mm, 24 mm
- Allen keys: 3, 4 and 5 mm
- Flat-blade screwdrivers:
- Assembly grease
- Loctite® 243 (medium strength thread locker)

5.4 Mounting preparations

1. Ensure all accessories are available (please refer to Chapter 10 Dimension drawings).



NOTES!

Fastening screws and earth cable are not included in the range of supply.

2. Preparing the place of attachment: Clean the (motor) shaft, centering, bolting surfaces and fastening threads; check for damage. Repair any damage!

5.5 Mounting hollow-shaft type FGH 40

5.5.1 Standard (type P with feather key, type K with clamping without feather key)




Figure.1

1. Mount adapter shaft (1) and align using dial gauge.



NOTES!

The maximum radial run-out of the adapter shaft is 0.05 mm.

If necessary, use the ball thrust adjustment screw to align the adapter shaft. Secure ball thrust screws with Loctite® 243. Remove unused ball thrust screws or secure with Loctite® 243. Max. tightening torque for M12 approx. 25 Nm, for M16 approx. 35 Nm.

Use parallel keys to DIN 6885.

Please also observe the supplement data sheet *Mounting accuracy for hollow shaft encoders*.

You should also observe the Installation instructions supplied with the adapter shaft when installing!

2. Lightly grease the adapter shaft.
3. Secure the torque bracket (3) to the hollow-shaft device (13) with 4 tensilock screws (2).



NOTES!

When fitting to the device is possible to align the torque bracket in four different directions. If possible fit the device in a manner that ensures the cable gland points downwards! Exchange the position of the cable gland (12) and the blanking plug on the opposite side, if necessary.

4. Mount the hollow-shaft device to the adapter shaft.
5. Secure the hollow-shaft device with the aid of the axial tensioning disc (6) and a hexagon socket head cap screw (7).



NOTES!

The axial tensioning disc is supplied with several hexagon head socket cap screws of different lengths. To select the suitable hexagon head socket cap screw please refer to the dimensioning drawings in Chapter 10.
The hexagon head socket cap screws are coated with a microencapsulated adhesive as locking agent.

6. Fit the cover (14) and secure with four countersunk screws (15) to seal the hollow-shaft device.
7. Fastening the torque bracket:

Fastening without base plate:

Secure the link rod head (11) of the link rod (8) to a fixed point (for example on the motor housing).

Fastening with base plate:

Secure the base plate (9) to a fixed point with two hexagon head screws (10) – (for example on the motor housing or the foundations).



NOTES!

Once fitted the link rod must rotate easily around the link rod heads! Failure to observe this point may result in damage to the bearings!




NOTES!

The link heads are maintenance free. However, ensure they remain free from soiling and paint!

5.5.2 Hollow shaft with clamping ring and blind hole (type R with inch dimensions)


Tighten the clamping ring only after assembly by means of the clamping screw in order to prevent deformation of the hollow shaft.



Tightening torque clamping screw:

ISO 4762 - M4 x 14 - A2-70 **2,5 Nm**

ISO 4762 - M5 x 16 - A2-70 **5 Nm**



1. Loosen screw plug (1)
2. Mounting according to chapter 5.5.1 point 1 to point 4
3. Screw in the enclosed M6 cap screw with sealing ring (2)
Tightening torque: 8.5 Nm
4. Check: O-ring 25 x 2 [FKM] present (3)
Screw the screw plug back in (1)

5.6 Installation

5.6.1 General rules

NOTES!

In environments with high drive power, external systems can generate high electromagnetic emissions. Adverse effects on FGH 40 operation can be avoided by observing the following guidelines:

- Uninterrupted, low-resistance machine grounding must be ensured across all parts of a plant. Ensure that the connections have good electrical contact. Poor conductivity can be caused, for example, by paint, lubricants, corrosion or similar. In practice, large cable cross-sections are required for low-resistance machine grounding.
- Generous mounting distances must be maintained from actuators with a high energy density, such as contactors, inverters, motors, solenoid valves and brakes.
- Shielding of cables must be carried out professionally, for example between the inverter and motor. Please observe the manufacturer's specifications.
- Inductances of relays, contactors, solenoid valves or brakes should be wired with suppressors. To prevent conducted interference coupling, this is necessary for relays or contactors that are connected directly to the inputs or outputs (IO). To prevent interference coupling via the air path, this also applies to all inductances in the near field of the installation. Suppressors must be connected directly to the coil: RC elements or varistors for operation with alternating current (AC) and freewheeling diodes or varistors for operation with direct current (DC), whereby freewheeling diodes are preferable.
- The FGH 40 is operated with low voltage of up to 30 V. To avoid interference coupling via the air path, it is important to plan cable routes with sufficient distance to power lines in accordance with the following diagram. This generally applicable diagram is to be used for all connections **inside** and **outside** control cabinets.






Figure : Scheme for planning cable routes

5.6.2 Connecting

	<ul style="list-style-type: none"> • Sufficient dimensioning of the power supply. • The conductor cross-section of the power supply cable must be designed so that the maximum voltage drop is less than 3 V. A wire cross-section of 0.75 mm² is recommended. Permissible cable diameter: 6,5...9,5 mm. (Cable diameter for UL-listed devices 8...9,5 mm). • A DC distribution network can comprise considerable cable lengths, which may be subject to interference. It is recommended that the FGH 40 is not operated on a heavily disturbed DC distribution network. If necessary, a separate power supply should be provided. To minimize interference, the DC distribution should be connected to the power supply unit in a star configuration and with symmetrical routing of the forward and return conductors (as a "twisted pair" or as a cable). • A shielded supply cable must be used for the electrical connection. The cable shield must be connected to the machine grounding on both sides. Shield connection terminals must be used to connect the cable shielding to a large surface area in the switch cabinet. The same applies to the shielding of signal cables. • A cable for connecting to ground potential must be connected to the ground terminal of the FGH 40, if not already pre-assembled (max. tightening torque 2.0 Nm). • A flat grounding strap consisting of fine stranded wire with a minimum cross-section of 6 mm² must be used for grounding. • The grounding strap must be permanently and permanently connected to a low-impedance, nearby grounding point on the system side. The grounding point must be bare metal, free of paint, non-conductive surface finishes, grease, oil and corrosion. The length of the grounding strap should not exceed 2 m.
---	---

5.6.3 Shield contacting for EMC cable gland with cone



Example –Figure: Cable gland with cone

The shield is placed on the cone. The insulation must be removed at this point. The shielding must remain intact in this area and must not be damaged.

5.6.4 Connecting the fiber optic cable

The fiber optic cable is inserted into the terminal box of the FGH 40 via the second cable gland and is connected to a ST plug at the fiber optic output. Several sealing inserts for different cable diameters are included with the basic unit for the FO cable gland. The outer sheath of the fiber optic cable must be firmly seated in the sealing insert of the cable gland. In the terminal box, the fiber optic cable without an outer sheath must be laid in a loop without kinks.



Figure: Fiber optic cable and supply cable in the terminal box of the FGH 40

For fixed cable installations, either a non-slotted or a slotted sealing insert in the sizes 2 x 3 mm, 1 x 5...8 mm, 1 x 7...10.5 mm can be used in the cable gland of the fiber optic cable. The non-slotted sealing insert requires a tool to fit the ST plug due to the narrow internal diameter. Slotted sealing inserts enable device installation with pre-assembled fiber optic cables.



ATTENTION!

UL-/CSA-conformity is only given for the non-slotted sealing insert (pre-assembled). When using a slotted sealing insert (enclosed), the UL-/CSA test mark must therefore be covered with the enclosed sticker.

5.7 Dismantling

5.7.1 Safety instruction

Personnel

Dismantling must be carried out by skilled technical staff only.



WARNING!

Observe the safety instructions contained in **Chapter 2** when dismantling the device!



NOTES!

Do not use a hammer or similar tool when installing the device due to the risk of damage occurring to the bearings or coupling!

5.7.2 Dismantling hollow- shaft type FGH 40

Disconnect all electrical cable prior to beginning any work.

To dismantling the encoder follow the instructions given in Chapter 5.5 in the reverse order.

NOTES!

Use the withdrawal device D-53663a (available as an accessory) if you are unable to remove the device manually from the adapter shaft after having removed the axial tensioning disc)!



i

Special tool Withdrawal device D-53663a (type P and type K)

Using the withdrawal device, which is screwed into the withdrawal thread M25 x 0.75 of the hollow shaft allows you to remove the overspeed switch from the adapter shaft without risking damage to the bearings.

Hollow shaft with blind hole and clamping ring (type R):

Use screw / threaded rod M6 for forcing (L= min. 125 mm).

5.8 Electrical connection and start up



NOTES!

You must observe applicable EMC guidelines when routing cables!



NOTES for UL and CSA!

Do only use copper cables

5.8.1 Preparing cables

1. Strip cable insulation.
2. Crimp wire-end ferrules.

5.8.2 Electrical connection

1. Open the terminal box cover (16).



CAUTION!

Do not allow moisture to enter the terminal box when the cover is open!

2. Remove the cap of the cable gland (12, Fig.1).
3. Feed the cable into the terminal box trough the cable gland.



NOTES!

The signal cable shielding can be connected directly to the housing via the EMC cable gland. A coil spring intergrated in the cable gland ensures all-round contact is made with the bare cable shielding to ensure a good shield connection. This type fo shield connection should be preferred.

Alternatively, if equipotential boning currents are anticipated it is possible to connect the cable shielding to a shield terminal in the terminal box. A capacitor between the shield terminal and the encoder housing prevents the flow of equalizing current.

To achieve an effective shielding the cable shield must also be connected in the electrical cabinet.

4. Tighten the cable gland and blanking plugs using a spanner.



NOTES!

Prior to delivery cable glands and blanking plugs are tightened finger tight only. To ensure that the terminal box is reliably sealed tighten all cable glands and blanking plugs before starting up for the first time.

5. Use a spanner to tighten the cable gland until the cable is securely clamped and properly sealed.

**NOTES!**

Prevent lateral pulling forces acting on the cable and plugs so as not to impair the degree of protection of the cable gland.

6. Connect the supply voltage and signal cable (please refer to the connection diagrams, Chapter 11).

**CAUTION!**

Do not apply supply voltage to the signal outputs, as this will destroy the device!

7. Applicable to alternative shield connection only: fit cable lug to cable shield and connect to the shield terminal (please refer to the connection diagrams, Chapter 11).

**NOTES!**

To achieve a good shielding effect the cable shield be kept as short as possible.

8. Close the terminal box cover.

**NOTES!**

Before closing the terminal box cover check and if necessary clean both seal surfaces and the gasket.

**CAUTION!**

Ensure when closing the terminal box cover that no cable becomes jammed.

9. Secure earth cable to earth terminal.

6 Faults

6.1 Faults table

Faults	Possible cause	Remedy
Moisture in the terminal box	Soiled terminal box gasket or seal surfaces	Clean terminal box gasket and seal surfaces
	Damaged terminal box gasket	Replace terminal box gasket
	Cable gland/blanking plug not tightened	Tighten cable gland/blanking plug
	Unsuitable cable for cable gland	Use suitable cable and cable glands
No output signals	Supply voltage not connected	Connect supply voltage
	Connection cable reversed	Wire correctly
Output signals subject to interference	Unsuitable cable	Use data cable with conductors arranged as twisted pairs and common shield
	Cable shield not connected	Connect cable shield at both ends
	Cable routing not EMC compliant	Observe applicable EMC guidelines when routing cables
Signal interruptions	Signal end stage overloaded	Check pin assignment; observe connection diagram
		Do not assign unused outputs
	Outputs short-circuited	Do not connect outputs with supply voltage or GND
Contact Hübner-Service (page 2) if none of the remedies listed above provides a solution)!		

7 Inspections

7.1 Safety instructions


WARNING!

Skilled technical staff only are permitted to inspect the device and its installation. Observe the safety instructions contained in **Chapter 2** when inspecting or working on the device!

7.2 Maintenance information

The device is maintenance-free. However, to guarantee optimum fault-free operations we recommend that you carry out the following inspections.

7.3 Inspection schedule

Interval	Inspections
Yearly	Ensure the fastening screws are properly tightened
	Ensure cable connections and connection terminals are securely seated
Following approx 16 000 ... 20 000 hours of operation / higher levels of continuous load	Check deep groove ball bearings are running smoothly and listen for running noises

8 Disposal

8.1 Disposal procedure

The manufacturer is not obliged to take back the device.

The device is classed as electronic equipment and subject to the WEEE Directive; observe local, country-specific laws when disposing of the device.

For information on environmentally sound disposal please contact your local authority or a specialist disposal company.

9 Spare Parts


The in the following listed spare parts can be covered when required about the service address on the page 2.

Spare part	Remark
Cover	Cover of the hollow- shaft bore (non drive end)
Cable gland	M20 x 1,5
Terminal box cover	Incl. Sealing and screws

10 Dimension drawings

Further dimension drawings on our website or on request.


10.1 Construction type hollow- shaft



FGH 40 K../20 P Gew

Hollow- Shaft Ø 20, length of customer shaft max. 83 mm

HM 09 M 102530a




FGH 40 KK../20 P Gew

Hollow- Shaft Ø 20, length of customer shaft max. 83 mm

HM 09 M 102531a

JOHANNES
HÜBNER
GLIessen






FGH 40 KK../20 P Gew
Option S

Redundant version or with integrated option S


HM 10 M 103037a

JOHANNES
HÜBNER
GLIessen






JOHANNES
HUBNER
GIESSEN



FGH(J) 40 LL

additional dimension drawing
electric connection implementation fiber optic HM 11 M 103758d




FGH 40 S/SS

additional dimension drawing
electric connection implementation FGH 40 S/SS HM 12 M 105755
15 pole EMC

11 Connection diagrams

Shielding:

The shield of the signal cable can be connected directly to the housing of the encoder by the cable gland. Alternatively the shield of the signal cable can be connected to K11 via a capacitor(10nF / 500V) to the housing of the encoder.




Klemmkasten Terminal box		Anschlussplan Connection diagram PN109-400		
1	0V		GND	GND
2	12...30V		Versorgungsspannung	Power Supply
3	0°		Inkr. Ausgang 0°	Incr. Output 0°
4	0°		Inkr. Ausgang 0° Invers	Incr. Output 0° Inverse
5	90°		Inkr. Ausgang 90°	Incr. Output 90°
6	90°		Inkr. Ausgang 90° Invers	Incr. Output 90° Inverse
7	N		Nullimpuls	Reference
8	N		Nullimpuls Invers	Reference Inverse
9	ERR		Fehlerausgang (Low aktiv)	Error Output (Low active)
10	ERR		Fehlerausgang (High aktiv)	Error Output (High active)

FGH 40

Standard


Terminal box



10 pole printed circuit spring terminal block
type Phoenix ZFKDS

Connection data:
wire section
0,2-1,5 [mm²]

Alternative Shielding




Klemmkasten Terminal box		Anschlussplan Connection diagram PN109-401		
1	0V		GND	GND
2	12...30V		Versorgungsspannung	Power Supply
3	0°		Inkr. Ausgang 0°	Incr. Output 0°
4	0°		Inkr. Ausgang 0° Invers	Incr. Output 0° Inverse
5	90°		Inkr. Ausgang 90°	Incr. Output 90°
6	90°		Inkr. Ausgang 90° Invers	Incr. Output 90° Inverse
7	-		nicht belegt	not connected
8	-		nicht belegt	not connected
9	ERR		Fehlerausgang (Low aktiv)	Error Output (Low active)
10	ERR		Fehlerausgang (High aktiv)	Error Output (High active)

FGH 40

Standard without reference pulse

Terminal box

Socket insert view



Crimp contacts for cross-sectional data of wire from 0,52 up to 1,5 mm²

Shield:

The shield of the signal cable is directly to be connected with the socket housing.

Crimping tool: Burndy® No. MR 8 GE 5

Burndy-Stecker		Anschlussplan		PN109-410	
Burndy plug		Connection diagram		PN109-410	
1	A	0V		GND	GND
2	B	12..30V		Versorgungsspannung	Power Supply
3	C	0°		Inkr. Ausgang 0°	Incr. Output 0°
4	D	0°		Inkr. Ausgang 0° Invers	Incr. Output 0° Inverse
5	E	90°		Inkr. Ausgang 90°	Incr. Output 90°
6	F	90°		Inkr. Ausgang 90° Invers	Incr. Output 90° Inverse
7	G	N		Nullimpuls	Reference
8	H	N		Nullimpuls Invers	Reference Inverse
9	J	ERR		Fehlerausgang (Low aktiv)	Error Output (Low aktiv)
10	K	ERR		Fehlerausgang (High aktiv)	Error Output (High aktiv)
11	L	-		nicht belegt	not connected
12	M	-		nicht belegt	not connected

FGH 40

Standard

Burndy® plug

Connection cable

6x2x0,56 twin-standard, shielded

Type: HE-2LVCC-CY AWG 20b
acc. to VDE 0881

Cross-section: 0,56 mm²
Temperature: -20 °C to + 105 °C
Outside dia: 10,1 mm

shield is connected to casing


other cables- / temperature ranges
on request

Anschlusskabel		Anschlussplan		PN109-420	
Connection cable		Connection diagram		PN109-420	
1	A		schwarz black	0V	GND
2	B		rot red	12..30V	Versorgungsspannung
3	C		orange orange	0°	Inkr. Ausgang 0°
4	D		schwarz black	0°	Inkr. Ausgang 0° Invers
5	E		blau blue	90°	Inkr. Ausgang 90°
6	F		schwarz black	90°	Inkr. Ausgang 90° Invers
7	G		gelb yellow	N	Nullimpuls
8	H		schwarz black	N	Nullimpuls Invers
9	J		grün green	ERR	Fehlerausgang (Low aktiv)
10	K		schwarz black	ERR	Fehlerausgang (High aktiv)
11	L		-	-	nicht belegt
12	M		-	-	nicht belegt

FGH 40

Standard

Connection cable




12 pole printed circuit spring terminal block type
Phoenix ZFKDS

Connection data:
Wire section
0,2-1,5 [mm²]

Shielding:

The shield of the signal cable can be connected directly to the housing of the encoder by the cable gland. Alternatively the shield of the cable can be connected to K13 via a capacitor (10nF / 500V) to the housing of the encoder.

Alternative Shielding




Klemmkasten Terminal box		Anschlussplan Connection diagram PN109-430		
1	0V		GND	GND
2	12...30V		Versorgungsspannung Power Supply	
3	0°		Inkr. Ausgang 0° Incr. Output 0°	Incr. Output 0°
4	0°		Inkr. Ausgang 0° Invers	Incr. Output 0° Inverse
5	90°		Inkr. Ausgang 90°	Incr. Output 90°
6	90°		Inkr. Ausgang 90° Invers	Incr. Output 90° Inverse
7	N		Nullimpuls	Reference
8	N		Nullimpuls Invers	Reference Inverse
9	ERR		Fehlerausgang (Low aktiv)	Error Output (Low active)
10	ERR		Fehlerausgang (High aktiv)	Error Output (High active)
11	2F		Option 2F	Option 2F
12	2F		Option 2F invers	Option 2F inverse

FGH 40

Option F2

Terminal box




10 pole printed circuit spring terminal block
type Phoenix ZFKDS

Connection data:
Wire section
0,2-1,5 [mm²]

Shielding:

The shield of the signal cable can be connected directly to the housing of the encoder by the cable gland. Alternatively the shield of the cable can be connected to K13 via a capacitor (10nF / 500V) to the housing of the encoder.

Alternative Shielding




Klemmkasten Terminal box		Anschlussplan Connection diagram PN109-440		
1	0V		GND	GND
2	12...30V		Versorgungsspannung Power Supply	
3	0°		Inkr. Ausgang 0° Incr. Output 0°	Incr. Output 0°
4	0°		Inkr. Ausgang 0° Invers	Incr. Output 0° Inverse
5	90°		Inkr. Ausgang 90°	Incr. Output 90°
6	90°		Inkr. Ausgang 90° Invers	Incr. Output 90° Inverse
7	N		Nullimpuls	Reference
8	N		Nullimpuls Invers	Reference Inverse
9	ERR		Fehlerausgang (Low aktiv)	Error Output (Low active)
10	ERR		Fehlerausgang (High aktiv)	Error Output (High active)
11	B		Option B	Option B
12	B		Option B invers	Option B inverse

FGH 40

Option B

Terminal box




12 pole printed circuit spring terminal block type
Phoenix ZFKDS

Connection data:
Wire section
0,2-1,5 [mm²]

Shielding:
The shield of the signal cable can be connected directly to the housing of the encoder by the cable gland. Alternatively the shield of the cable can be connected to K13 via a capacitor (10nF / 500V) to the housing of the encoder.

Alternative Shielding




Klemmkasten		Anschlussplan		PN109-450	
Terminal box		Connection diagram		PN109-450	
1	0V		GND	GND	
2	12...30V		Versorgungsspannung	Power Supply	
3	0°		Inkr. Ausgang 0°	Incr. Output 0°	
4	0°		Inkr. Ausgang 0° Invers	Incr. Output 0° Inverse	
5	90°		Inkr. Ausgang 90°	Incr. Output 90°	
6	90°		Inkr. Ausgang 90° Invers	Incr. Output 90° Inverse	
7	N		Nullimpuls	Reference	
8	N		Nullimpuls Invers	Reference Inverse	
9	ERR		Fehlerausgang (Low aktiv)	Error Output (Low active)	
10	ERR		Fehlerausgang (High aktiv)	Error Output (High active)	
11	B2		CW ... CCW ... Stop	Option B2	
12	B2		CW ... CCW ... Stop	Option B2 invers	

FGH 40

Option B2

Terminal box




10 pole printed circuit spring terminal block type
Phoenix ZFKDS

Connection data:
Wire section
0,2-1,5 [mm²]

Shielding:
The shield of the signal cable can be connected directly to the housing of the encoder by the cable gland. Alternatively the shield of the cable can be connected to K13 via a capacitor (10nF / 500V) to the housing of the encoder.

Alternative Shielding




Klemmkasten		Anschlussplan		PN109-460	
Terminal box		Connection diagram		PN109-460	
1	0V		GND	GND	
2	12...30V		Versorgungsspannung	Power Supply	
3	0°		Inkr. Ausgang 0°	Incr. Output 0°	
4	0°		Inkr. Ausgang 0° Invers	Incr. Output 0° Inverse	
5	90°		Inkr. Ausgang 90°	Incr. Output 90°	
6	90°		Inkr. Ausgang 90° Invers	Incr. Output 90° Inverse	
7	N		Nullimpuls	Reference	
8	N		Nullimpuls Invers	Reference Inverse	
9	ERR		Fehlerausgang (Low aktiv)	Error Output (Low active)	
10	ERR		Fehlerausgang (High aktiv)	Error Output (High active)	
11	B3		CW ... CCW ...	Option B3	
12	B3		CW ... CCW ...	Option B3 invers	

FGH 40

Option B3


Terminal box



2 pol. Print-Zugfederklemme Typ Phoenix ZFKDS
2 pole printed circuit spring terminal block type Phoenix ZFKDS

Anschlussdaten:
Aderquerschnitt
0,2-1,5 [mm²]

Connection data:
wire section
0.2-1.5 [mm²]



Anschlussdaten:
ST-Steckverbinder
1 Glasfaser 50/125µm
oder
1 Glasfaser 62.5/125µm


Connection data:
ST connector
1 Fibre optic cable 50/125µm
or
1 Fibre optic cable 62.5/125µm

Klemmkasten Terminal box	Anschlussplan Connection diagram	PN109-470 PN109-470
1	12...30V DC	Power Supply
2	0V	GND
3	LWL	Fibre Optic Cable

Schirmung:
Der Schirm der Signalleitung kann über die Kabelverschraubung direkt mit dem Gehäuse verbunden werden.
Alternativ kann der Kabelschirm an K11 über einen Kondensator (4,7nF / 250V AC) mit dem Gebergehäuse verbunden werden.


Shielding:
The shield of the signal cable can be connected directly to the housing of the encoder by the cable gland.
Alternatively the shield of the signal cable can be connected to K11 via a capacitor (4.7nF / 250V AC) to the housing of the encoder.

**Alternativer Schirmanschluss
Alternative Shielding**



Ansicht auf Steckdoseneinsatz

Socket insert view



Anschlussdaten:

Crimpkontakte für Drahtquerschnitte
0,75-1,0 [mm²]

Connection data:

Crimp contacts for cross-sectional data of wire
0,75-1,0 [mm²]

Schirmung:

Der Schirm der Signalleitung muss über
die Kabelverschraubung direkt mit dem
Gehäuse verbunden werden.

Shielding:

The shield of the signal cable has to be
connected directly to the housing of the
encoder by the cable gland.

EMV-Industriestecker		Anschlussplan		PN109-415	
EMC industrial plug		Connection diagram		PN109-415	
C5	0V		GND	GND	
A5	12...30V		Versorgungsspannung	Power Supply	
A1	0°		Inkr. Ausgang 0°	Incr. Output 0°	
A2	0°		Inkr. Ausgang 0° Invers	Incr. Output 0° Inverse	
A3	90°		Inkr. Ausgang 90°	Incr. Output 90°	
A4	90°		Inkr. Ausgang 90° Invers	Incr. Output 90° Inverse	
B3*	N		Nullimpuls	Reference	
B4*	N		Nullimpuls Invers	Reference Inverse	
B5	ERR		Fehlerausgang (Low aktiv)	Error Output (Low active)	
C3	ERR		Fehlerausgang (High aktiv)	Error Output (High active)	
C1*	2F		Option 2F	Option 2F	
C2*	2F		Option 2F invers	Option 2F inverse	
C1*	B		Option B	Option B	
C2*	B		Option B invers	Option B inverse	
C1*	B2		Rechtslauf	clock wise	
C2*	B2		Linkslauf	counter clock wise	


* optional je nach Ausführung
depending on options

FGH 40

Connection scheme PN 109-415

EMC industrial plug

Ansicht auf Steckdoseneinsatz View on device connector



	M	
	H	
	A	
	B	
	C	
	D	
	E	
	F	


- c +12V...+30VDC Versorgungsspannung
Supply voltage
- c GND
- o Schaltausgang 1
Switching output 1
- o Schaltausgang 2
Switching output 2
- o Systemüberwachung
System check

Crimpkontakte für Drahtquerschnitte 0,52 bis 1,5 mm
Crimping tool: Burndy No. MR 8 GE 5

FGH 40

Connection scheme 649 Option S

Burndy® plug



10 pol. Print-Zugfederklemme Typ Phoenix ZFKDS

10 pole printed circuit spring terminal block type Phoenix ZFKDS

Anschlussdaten:

Aderquerschnitt

0,2-1,5 [mm²]

Connection data:

wire section

0.2-1.5 [mm²]

Klemmkasten Terminal box		Anschlussplan PN148-400b Connection diagram PN148-400b		
1	0V		GND	GND
2	5...30V DC		Versorgungsspannung	Power Supply
3	A+		Ausgang A+	Output A+
4	A-		Ausgang A-Invers	Output A-Inverse
5	B+		Ausgang B+	Output B+
6	B-		Ausgang B-Invers	Output B-Inverse
7	N		Nullimpuls	Reference
8	\overline{N}		Nullimpuls Invers	Reference Inverse
9	ERR		Fehlerausgang (Low aktiv)	Error Output (Low active)
10	\overline{ERR}		Fehlerausgang (High aktiv)	Error Output (High active)

FGH 40

Connection sheme PN 148 400b

Sinue /Cosine Output